

Installation Guide

The processes that need to be completed by the installer

1. Joining two adjacent cabinets
2. Attaching the doors to the cabinets
3. Attaching shelves on the cabinets
4. Attaching skin panel on the exposed side
5. Attaching sliders & clips for drawers
6. Attaching door handle/ doorknobs on door of the cabinet
7. Attaching any accessories-crown molding, fillers etc

Joining Two cabinets:

1. Align the cabinets adjacently using laser guides or marks as per requirement



2. Clamp the sides of both the cabinets frames. Ensure that the frames align properly vertically and from the front.

3. After securing the frames together pre-drill at the bottom and top of the frames where you will be screwing them together.



Drill 1 & 3/4" deep to ensure that 2-inch screw tightly fits between the cabinets

4. Placement of these pre-drill holes can be near the existing pre-drilled hole meant for installation of the hinges.



Placement of Drill Holes on top and bottom

Attaching door to the frame of cabinets:

Door Hinge is attached just above the drill hole at Top and Bottom to completely conceal it



Attaching Shelves on the cabinets:

Installation of the shelves need to be done on site so that they are exactly to the client's specific needs.



To ensure the flexibility of shelf height press-in studs are provided.



Attaching skin panel on the exposed side

1. Measure the length and width for exposed side accurately. Ensure all the gaps between wall and cabinets are covered in the measurement
2. Cut the skin panel as per the dimensions taken
3. Apply glue to the skin panel



4. Carefully align the skin panel at side and ensure there are no gaps



5. Tape the skin panel with quality painters tape to ensure a strong bond

